

Tyann LVT Installation Quick Guide – Manufacturer Requirement

1. Prepare/level the substrate (e.g., concrete)
2. Set room AC to 65-85°F
3. Do moisture testing, humidity should be 30% to 50%
4. Acclimate the LVT
 - a. remove the LVT from boxes
 - b. leave the LVT in the room for min. 24 hours before installation
5. Apply glue, wait for glue to set (e.g., 30 to 60 minutes) dry to the touch
6. Lay down the LVT boards
7. Roll the LVT boards with a 100lbs roller
8. Leave AC on (65-85°F) for at least 24 hours after installation

No manufacturing warranty if this guide is not followed.

For more information, please visit www.tyannflooring.com.

Guía rápida de instalación de Tyann LVT - Requisito del fabricante

1. Preparar/nivelar el sustrato (por ejemplo, hormigón)
2. Configure el aire acondicionado de la habitación a 65-85 ° F
3. Haga pruebas de humedad, la humedad debe ser del 30% al 50%
4. Aclimatar el LVT
 - a. Retire el LVT de las cajas
 - b. Deje el LVT en la habitación durante un mínimo de 24 horas antes de la instalación
5. Aplique pegamento, espere a que el pegamento se asiente (por ejemplo, de 30 a 60 minutos) y se seque al tacto
6. Coloque las tablas LVT
7. Enrolle las tablas LVT con un rodillo de 100 libras
8. Deje el aire acondicionado encendido (65-85 ° F) durante al menos 24 horas después de la instalación

No hay garantía de fabricación si no se sigue este guía.

Para obtener más información, visite www.tyannflooring.com.